


MASSAGE CHAIR

AT-2200 OPERATION



Thank you for purchasing AT-2200 massage chair.
Before you begin using your new chair, please read the operation manual thoroughly for the correct methods of usage, noting especially the section on Safety.

The manual should be kept available for future reference after you have read thoroughly.

PLEASE READ: To achieve the maximum results from your AT-2200, carefully read this manual.

CAUTION: Only for household use. Please read and observe these safety instructions carefully to reduce the possibility of injury.

● Those with the following conditions should consult their physician prior to using this massage chair.

- a) Malignant tumor
- b) Heart Disease
- c) Pregnancy
- d) Back Disease or back trouble from an injury or accident..

● Do not use your massage chair in an excessively humid or dusty environment.

● Your massage chair should be operated at room temperature of between 5 °C and 40 °C .

● Make sure all operation switches are in the off position before connecting power cord to an electrical outlet.

● Do not use attachments which are not recommended by the manufacture.

● If you detect a malfunction or any other abnormal condition in the operation for your chair, turn off the power immediately and disconnect the power cord from the outlet.

● If you feel severe discomfort during the operating of your massage chair, stop using the chair and consult your physician.

● You should not use the chair for more than 15 minutes at one time.

● If the chair got wet or exposed to moisture, turn the chair off, unplug it from the wall socket and call your place of purchase or its agent.

● Keep your massage chair clean and away from humidity.

Important Safety Instructions

Read all instructions before using the AT-2200

WARNING:

Read all instructions before using the AT-2200
WARNING: Do not put hands or fingers near the massage mechanism while the AT-2200 is running .

Touching the mechanism can result in injury from the rollers squeezing together.

If the supply cord is damaged ,it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally responsible recycling.



DANGER: *To reduce the risk of electrical shock*

Always unplug massager from the electrical outlet immediately after using and before cleaning.

Do not reach for an appliance that has fallen into water . Unplug immediately.

WARNING: *To reduce the risk of burns, fire, electric shock or injury to persons.*

An appliance should never be left unattended when plugged in.

Unplug from outlet when not in use, and before putting on or taking off parts.

Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock , or injury to persons.

Close supervision is necessary when this appliance is used by, on , or near children , invalids, or disabled persons.

Use this appliance only for its intended use as described in this manual. Do not use attachment not recommended by the manufacturer.

Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged , or dropped into water. Return the appliance to a service center for examination and repair.

Always keep the power cord away from heated surfaces.

Never operate the appliance with the air openings blocked.

Keep the air opening free of lint, hair and the like.

Never drop or insert any object into any opening.

Do not use outdoors.

Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

To disconnect, turn all controls to the OFF position, then remove plug form outlet.

Do not massage abdomen when pain is present or if you are pregnant.

Do not massage any area of the body that is swollen, inflamed or covered with skin eruptions.

Do not use on unexplained calf pain.

Do not use massager when standing on a damp floor, or when any part of the body is in contact with plumbing or any similar ground.

Always connect massager to a properly grounded electrical outlet.

Do not use unit if abnormal noise is heard.

The unit is designed for personal in-home use.

Commercial use will void warranty.

SAVE THESE INSTRUCTIONS

ENG

DEU

For all grounded cord-connected products:

Grounding Instructions:

This product must be grounded. If it should malfunction or breakdown , grounding provides a path of least resistance for electrical current to reduce the risk of electric shock. This product is equipped with a cord having an equipment grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.


WARNING: Improper connection of the equipment-grounding conductor can result in a risk of electronic shock. Check with a qualified electrician or serviceman if you are in doubt as to whether this product is properly grounded. Do not modify the plug provided with the product if it will not fit the outlet, have a proper outlet, have a proper outlet installed by a qualified electrician.

WARNING: Your chair is equipped with a thermal resetting protection device. This is an added safety feature to protect you and your massage chair from overheating. If the chair should suddenly stop and will not start, turn the main power switch, located on the back of the chair , off and do not operate the chair for at least 30 minutes. Failure to turn the chair off may result in the chair starting unexpectedly when the device cools.


Name of each part and function

Chair

Front side



Back side




Front side

- 1 Head pillow
When enjoying a massage, flip the head pillow over the backrest to increase neck and shoulder massage intensity
- 2 Backrest pad
Please lean on freely
- 3 Remote controller
To control operation
- 4 Remote controller pocket
Put the remote controller into the pocket

Back side

- 5 footrest rotation lever
Rotate the foot massager to be used as footrest
- 6 AC plug
- 7 AC cord
- 8 Power switch
Please set to OFF after usage


Remote controller




Name	
1	End
2	Stop
3	Auto programs "Full body " "Shoulders" "Low back"
4	Height Range
5	Width
6	Backrest up / Backrest recline
7	Footrest up/ footrest down
8	Manual Kneading/Percussion/ Kneading+Percussion
9	Position
10	Rolling Full/Partial
11	Foot calf

Get ready


Unpack the box, take out chair base and attachments




Chair Base



Backrest Pad





Seat Cushion



Head Pillow

Attach the seat cushion, backrest pad and head pillow

1. Attach the seat cushion
Align and press the seat cushion firmly into place




2. Zip the backrest pad to the chair.
Please attach the backrest pad before massage.



3. Attach the head pillow to the backrest pad


- During deep neck massage, flip the head pillow over the backrest to the back
- When a less intent massage is desired, place the pillow in a position that supports the head



How to place the chair

Make sure the area is flat and clear of any obstructions


- While reclining and footrest is being extended out, make sure there's no obstructions around with an allowance space of more than 15cm behind the chair and more than 65cm in front of the chair.
- Carpet etc. are recommended to spread under the chair to prevent any damage to the floor.
- Do not leave this product exposed to direct sunlight for long periods of time.
Do not store near heat or open flame.
This may cause fading or damage.




Get ready

Power on

1. Connect the AC plug to the electrical outlet
Make sure there is no damage on the power cord, remote controller cord and power plug.
2. Turn the master power switch (on the bottom of the chair) to on.



Recline the backrest and raise the footrest
Use the back and foot buttons to position the chair for maximum comfort.



For foot or calf massage

1. Extend the footrest massager.

Lift the footrest rotation handle to release the positioning lock.

To use for calf massage, rotate the footrest outwards from the chair until it clicks into position.

To use for foot massage, rotate the footrest outwards from the chair until the footrest is facing up but have not clicks into position. For foot massage, the footrest should be able to move freely and not locked into position as in calf massage.


Note :

For the backrest to raise, the footrest must be locked into position.



Do not use excessive force to rotate the footrest.

Do not try to rotate the footrest past its locked position.

Do not stand or sit on the foot and calf massager.



2. Insert your feet or calves.



OPERATION

Massage Modes	What It Does	Benefits
 Stretch	Kneads your back in a small, circular motion on both sides of your spine simultaneously.	Relieves tension and soreness by lifting and stretching muscles. Improves circulation and helps bring vital nutrients to the spinal area.
 Flex	Alternates rapid-tapping strokes along the spine to stimulate both spinal muscles and spinal joint areas, emulating the percussive massage technique used in sports medicine for deep muscle therapy.	Flexes spinal joints and relieves pressure on the spinal column, invigorating the entire back area.
 Tone	Combines circular kneading motion with rapid-tapping percussion strokes.	Relieves muscle tension and spinal pressure, improves circulation and invigorates the back, all at once.
 Glide	Rolls gently up and down your back near your spine.	Warms and loosens your muscles, preparing your back for deeper massage. Relieves muscle tension, improves circulation and relaxes the back.

Specifications

Operating Voltage	AC220-240V 50/60Hz
Power Consumption:	85 Watts
Chair Size	170cm L x 74cm W x 74cm H (reclined) 102cm L x 74cm W x 102cm H (upright)
Product Weight	50kg
Maximum load Weight	129kg

*Specifications are subject to change without prior notice.